

Programming Additional Key-Fobs (Remotes)—Optional

1. Locate the Program Button (Fig. 8) on the RF Receiver.
2. Press the Program Button until the red Status Light (Fig. 8) illuminates, then release the button and the Status Light will turn off.
3. Within five seconds, press any button on the key-fob (remote) (Fig. 6). Verify that the RF receiver Status Light blinks.
4. Repeat steps 1 and 2 for each additional remote.
5. Verify that each remote has been successfully programmed.

NOTE: To delete all key-fob remotes stored in memory, press and hold the Program Button for approximately five seconds until the red Status Light turns off.

Fig. 8

